

PROFESSIONAL TALK BACK INTERCOM OPERATION.

A) From the master station.

1) To call an other station.

- Select the desired station by dialling the corresponding number (See picture). A ringing tone will be heard or the line will "splash open" immediately depending on the way of programming.
- Start to communicate hands free. The speech direction is driven by the human voice.



2) To answer a call.

An incoming call will be announced by an acoustic tone and a red flashing LED showing the location of the calling station.

- Push the button "0" to accept the call and start to communicate hands free.

B) From another station.

- If the station is provided with a full keypad, dial the desired number and operate further on the same way as the master station noted here above.
- If the station has only one (1) "CALL" button, push the button, you will hear a ringing tone and wait until you get answer. Speak hands free. The speech direction is driven from the master station.

Master station.



Model EE880-K72

Field stations



Model EE472

Model PR-96018/EX

Model PSE-1